

# **Undercarriage Wash Systems**

Water Treatment Systems



# **WCU Series**

# Undercarriage Wash Systems



THE IDEAL ACCESSORY FOR ANY WASH BAY,
THIS SYSTEM HELPS TO REMOVE MUD AND GRIME
BUILD-UP UNDER VEHICLES AND SMALL EQUIPMENT.
THE DURABLE STEEL FRAME ENSURES LONGEVITY
EVEN IN HARSH CONDITIONS.

CUSTOM BUILT UNITS ARE AVAILABLE.
CONSULT DEALER FOR MORE INFORMATION.

#### **FEATURES**

- Powder coated frame with control box and pump
- 8-foot stainless-steel spray bar with 16 nozzles
- Auto shut-off valve
- 250-gallon holding tank, supply hose and make-up valve
- PLC controls for automatic pump operation with photo-eye and remote box
- ETL listed NEMA-4 rated corrosion-proof control panel

MODEL NUMBER	GPM @ PSI	PUMP	POWER REQUIREMENTS	SPRAY BAR COVER DIMENSIONS (LxWxH)	PUMP FRAME DIMENSIONS (LxWxH)	HOLDING TANK DIMENSIONS (WxH)	SHIP WT.
WCU-35-0ME1	35 @ 110	3.0 HP	230V, 1Ø, 15.0A	96x6x0.5in.	4x3x5ft.	36x62in.	450 lb.
WCU-35-0ME3	35 @ 110	3.0 HP	208-230V, 3Ø, 10.0A or 460V, 3Ø, 5.0A	96x6x0.5in.	4x3x5ft.	36x62in.	450 lb.

#### ACCESSORY:

PART NUMBER DESCRIPTION

TAITI NOMBER	DESCRIPTION	THOMOBLES
18-0017	Nozzles – Sixteen 15°, size 15 nozzles, for high undercarriages	All models
OPTIONS:		
PART NUMBER	DESCRIPTION	FITS MODELS
WX-0144	<b>460V, 30 –</b> Upgrades 208-230V model to operate at 460V	All models
WX-0146	Detergent - Adds chemical injector to bypass line of pump, chemical gets injected at inlet of pump	All models

FITS MODELS

# **WCU Series**

## Undercarriage Wash Systems



Sixteen 25°, size 15 nozzles spaced 6-inches apart, for low undercarriages





Remote box for auto/manual operation of spray bar






Photo-eye with 10-foot maximum range



Shut-off valve




Auto flow control solenoid that opens water flow valve when system is on and closes when off to prevent drainage



# **WCU Series**

### Process & Flow Description



- 1. INLET CONNECTION Connect a fresh water supply with at least 20-PSI to the water supply tank.
- 2. WATER SUPPLY TANK A 250-gallon tank with an automatic water level float valve supplies water to the system.
- 3. WATER SUPPLY VALVE Connects water supply tank to undercarriage wash system.
- 4. AUTO FLOW CONTROL Opens water flow valve when system is on, closes when off.
- 5. PHOTO-EYE Detects incoming vehicles and equipment and sends signal to start system.
- **6. MULTISTAGE WASH SYSTEM PUMP** A 3.0 HP, 13-stage centrifugal pump increases water pressure to 110-PSI to push through spray bar at 35.0-GPM.
- 7. SPRAY BAR Provides upward high impact spray for undercarriage cleaning.
- 8. PRESSURE GAUGE Measures pump pressure to monitor system performance.
- 9. CONTROL PANEL ETL listed NEMA-4 rated corrosion-proof control panel for safe and reliable operation.



9872 Kapp Court | Peosta, IA 52068 (800) 556-8866 | (563) 556-8866 www.mitmequipmentsales.com

